





























































Feature operation

AutoDial		
Store	AutoDial 	AutoDial 
Use		AutoDial 
Display	Display 	AutoDial 
Call Forward		
Activate	Fwd 	Fwd 
Deactivate		Fwd 
Reinstate	Fwd 	Fwd 
View number	Display 	Fwd 
Call Pickup		
		Pickup 
Call Waiting		
Answer		Call Waiting 
Return to first call		
Conference		
	Conf 	Conf 
Handsfree		
Activate		 (to end the call)
Switch to handset		
Handset to handsfree		
Activate Headset		
		 (to end the call)
Hold		
Place a call on hold		
Return to a held call		
Last Number Redial		
		
Message		
		 (Msg/Inbox)
Ring Again		
Activate	RngAgn 	
When notified		RngAgn 
Deactivate		RngAgn 
Transfer		
	Trans 	Trans 
Adjust volume		
	 (Volume +)	or  (Volume -)

Legend

Icon	Action
()	Indicates the key cap text label. For example, (Message).
	Lift the handset, press the line (DN) key or the Handset key.
	Replace the handset, or press  (Goodbye) to end the call.

Legend (continued)

Icon	Action
	Press a line/feature key.
	Dial a number.
	An icon flashes when a feature is being programmed. An icon lights steadily when a feature is active.
	Press the Services key once for Call Platform features, or press the Services key twice for local phone features.
	Press the Message/Inbox key.
	Press the Up/Down Navigation keys 
	Press the Enter key
	Press the Headset key.
	Press the Handsfree key.
	Press the Mute (on/off) key.
	Press the Directory key.
	Press the Quit/Stop key.

Services and Telephone Options menus

Services menu



Note: The **Services** menu contains the **Telephone Options**, **Password Admin**, **Virtual Office**, and **MG 1000B** menus. These options are not available on all Nortel IP Phone 1120E phones. Consult your system administrator.

The following are the most commonly used options:

Telephone Options menu

Volume adjustment

Pick one of:



Contrast adjustment



Language



Note: This language setting controls the language used by features on your phone only. To set the language used elsewhere on your phone, press **Services** twice, select 1. Preferences, and select 2. Language.

Date/Time format



Local DialPad Tone



Ring type



OnHook default path



Note: The **Directory** key provides access to Corporate Directory, Personal Directory, Redial List, and Callers List. For additional information about your IP Phone 1120E, consult the *Nortel IP Phone 1120E User Guide* (NN43112-103).

Nortel IP Phone 1120E



*Note: If supported by your server, the data message waiting indicator provides a data alert. Contact your system administrator to find out if this feature is available for you.



IP Phone 1120E

For Nortel Communication Server 1000

Quick Reference Card

